



MEASUREMENT GUIDE

Witect Wallpaper

Here's a step-by-step guide to help you measure your walls before ordering wallpaper:

1. Start by measuring the width of the wall. Use a measuring tape to measure from one end of the wall to the other, making sure to measure at the widest point if the wall is not perfectly straight. Round the measurement up to the nearest inch.
2. Next, measure the height of the wall. Use a measuring tape to measure from the floor to the ceiling, making sure to measure at the highest point if the ceiling is not perfectly level. Round the measurement up to the nearest inch.
3. Calculate the total square footage of the wall by multiplying the width and height measurements together. For example, if the width of the wall is 10 feet and the height is 8 feet, the total square footage of the wall is 80 square feet ($10 \times 8 = 80$).
4. If the wall has windows or doors, subtract their square footage from the total square footage of the wall. Measure the width and height of each window and door and multiply them together to calculate their square footage. Subtract the total square footage of the windows and doors from the total square footage of the wall to get the amount of wallpaper needed.
5. Keep in mind that our wallpaper is sold by the roll, with each roll covering a certain amount of square footage. To determine how many rolls of wallpaper you'll need, divide the total square footage of the wall by the square footage covered by each roll. Make sure to add extra for any pattern matching or waste.
6. Finally, when ordering your Wi-tect, always double-check the measurements and make sure you have enough rolls to cover the entire wall. It's also a good idea to order a little extra (15%) in case of mistakes or to have some left over for future repairs.

By following these steps, you should be able to accurately measure your walls and order the right amount of wallpaper for your project. If you have any questions you are more than welcome to contact us.

Team Wi-tect